



Empties Please

Manufacturer	Toner Model #
Brother	DR1050 - K
Brother	DR130 CL
Brother	DR2005-K
Brother	DR2100-K
Brother	DR2200-K
Brother	DR230 - CMY
Brother	DR2300
Brother	DR230-K
Brother	DR241 BK
Brother	DR241 CL
Brother	DR3000-K
Brother	DR3100-K
Brother	DR320 CL
Brother	DR3200-K
Brother	DR3300-K
Brother	DR4000-K
Brother	DR6000-K
Brother	TN (1050)
Brother	TN (2000)
Brother	TN (2005)
Brother	TN (2010)
Brother	TN (210) - C
Brother	TN (210) - K
Brother	TN (210) - M
Brother	TN (210) - Y
Brother	TN (2110/20)
Brother	TN (2150)
Brother	TN (2210/20)
Brother	TN (230) - C
Brother	TN (230) - K
Brother	TN (230) - M
Brother	TN (230) - Y
Brother	TN (2310/20)
Brother	TN (241/5) - C
Brother	TN (241/5) - K
Brother	TN (241/5) - M
Brother	TN (241/5) - Y
Brother	TN (3030/60)
Brother	TN (310/5) - C
Brother	TN (310/5) - K
Brother	TN (310/5) - M
Brother	TN (310/5) - Y
Brother	TN (3130/70)
Brother	TN (320/5/8) - C
Brother	TN (320/5/8) - K
Brother	TN (320/5/8) - M
Brother	TN (320/5/8) - Y
Brother	TN (321/6) - C
Brother	TN (321/6) - K
Brother	TN (321/6) - M
Brother	TN (321/6) - Y
Brother	TN (3230/80)
Brother	TN (3330/80/90)
Brother	TN1050
Brother	TN130-C

Manufacturer	Toner Model #
Brother	TN130-K
Brother	TN130-M
Brother	TN130-Y
Brother	TN135-C
Brother	TN135-K
Brother	TN135-M
Brother	TN135-Y
Brother	TN1700-K
Brother	TN2000
Brother	TN2005
Brother	TN2010
Brother	TN2110
Brother	TN2120
Brother	TN2150
Brother	TN2150 HC
Brother	TN2210
Brother	TN2220
Brother	TN230-C
Brother	TN230-K
Brother	TN230-M
Brother	TN230-Y
Brother	TN2310
Brother	TN2320
Brother	TN241 - C
Brother	TN241 - K
Brother	TN241 - M
Brother	TN241 - Y
Brother	TN245 - C
Brother	TN245 - M
Brother	TN245 - Y
Brother	TN3030
Brother	TN3060
Brother	TN310 - C
Brother	TN310 - K
Brother	TN310 - M
Brother	TN310 - Y
Brother	TN3130
Brother	TN315 - C
Brother	TN315 - K
Brother	TN315 - M
Brother	TN315 - Y
Brother	TN3170
Brother	TN3185
Brother	TN320 - C
Brother	TN320 - K
Brother	TN320 - M
Brother	TN320 - Y
Brother	TN321 - C
Brother	TN321 - K
Brother	TN321 - M
Brother	TN321 - Y
Brother	TN3230
Brother	TN325 - C
Brother	TN325 - K
Brother	TN325 - M

Manufacturer	Toner Model #
Brother	TN325 - Y
Brother	TN326 - C
Brother	TN326 - K
Brother	TN326 - M
Brother	TN326 - Y
Brother	TN328 - C
Brother	TN328 - K
Brother	TN328 - M
Brother	TN328 - Y
Brother	TN3280
Brother	TN3330
Brother	TN3380
Brother	TN3390
Brother	TN348 - C
Brother	TN348 - K
Brother	TN348 - M
Brother	TN348 - Y
Brother	TN4100
Brother	TN5500
Brother	TN6300
Brother	TN6600
Brother	TN7300
Brother	TN7600



Empties Please

Manufacturer	Toner Model #
Canon	119-K
Canon	120-K
Canon	707-C
Canon	707-K
Canon	707-M
Canon	707-Y
Canon	708H-K
Canon	708-K
Canon	710H-K
Canon	710-K
Canon	711-C
Canon	711-K
Canon	711-M
Canon	711-Y
Canon	712-K
Canon	713-K
Canon	714
Canon	715H-K
Canon	715-K
Canon	716 -C Starter
Canon	716 -K Starter
Canon	716 -M Starter
Canon	716 -Y Starter
Canon	716-C
Canon	716-K
Canon	716-M
Canon	716-Y
Canon	718 -C Starter
Canon	718 -K Starter
Canon	718 -M Starter
Canon	718 -Y Starter
Canon	718-C
Canon	718-K
Canon	718-M
Canon	718-Y
Canon	719
Canon	719H
Canon	720 - K
Canon	720H - K
Canon	723 -C Starter
Canon	723 -K Starter
Canon	723 -M Starter
Canon	723-C
Canon	723H-K
Canon	723-K
Canon	723-M
Canon	723-Y
Canon	724H-K
Canon	724-K
Canon	725 -K Starter
Canon	725-K
Canon	726 -K Starter
Canon	726-K
Canon	728 -K Starter
Canon	728-K
Canon	729 - C
Canon	729 - C Starter
Canon	729 - K

Manufacturer	Toner Model #
Canon	729 - K Starter
Canon	729 - M
Canon	729 - M Starter
Canon	729 - Y
Canon	729 - Y Starter
Canon	731 - C
Canon	731 - C Starter
Canon	731 - K
Canon	731 - M
Canon	731 - M Starter
Canon	731 - Y
Canon	731 - Y Starter
Canon	731H - K
Canon	732 - C
Canon	732 - C Starter
Canon	732 - K
Canon	732 - K Starter
Canon	732 - M
Canon	732 - M Starter
Canon	732 - Y
Canon	732 - Y Starter
Canon	732H - K
Canon	A-30-K
Canon	C-EXV12
Canon	C-EXV28 - C
Canon	C-EXV28 - K
Canon	C-EXV28 - M
Canon	C-EXV28 - Y
Canon	C-EXV29 - C
Canon	C-EXV29 - K
Canon	C-EXV29 - M
Canon	C-EXV29 - Y
Canon	C-EXV34 - C
Canon	C-EXV34 - K
Canon	C-EXV34 - M
Canon	C-EXV34 - Y
Canon	C-EXV35
Canon	C-EXV36
Canon	C-EXV38
Canon	C-EXV39
Canon	C-EXV47
Canon	CRG H-K
Canon	E-30-K
Canon	EP-27-K
Canon	FX-10-K



Manufacturer	Toner Model #
Dell	1130 HC-K
Dell	1130-K
Dell	1133-K
Dell	1135-K
Dell	113X - K
Dell	1230-C
Dell	1230-K
Dell	1230-M
Dell	1230-Y
Dell	1250 HC-C
Dell	1250 HC-K
Dell	1250 HC-M
Dell	1250 HC-Y
Dell	1250-C
Dell	1250-K
Dell	1250-M
Dell	1250-Y
Dell	1320 HC - C
Dell	1320 HC - K
Dell	1320 HC - M
Dell	1320 HC - Y
Dell	1320-C
Dell	1320-K
Dell	1320-M
Dell	1320-Y
Dell	1350 HC-C
Dell	1350 HC-K
Dell	1350 HC-M
Dell	1350 HC-Y
Dell	1350-C
Dell	1350-K
Dell	1350-M
Dell	1350-Y
Dell	1355 HC-C
Dell	1355 HC-K
Dell	1355 HC-M
Dell	1355 HC-Y
Dell	1355-C
Dell	1355-K
Dell	1355-M
Dell	1355-Y
Dell	1600 HC-K
Dell	1600-K
Dell	1700 DRUM-K
Dell	1700-K
Dell	1710-K
Dell	1720 DRUM-K
Dell	1720-K
Dell	1815 HC-K
Dell	1815-K
Dell	2130 HC-C
Dell	2130 HC-K
Dell	2130 HC-M
Dell	2130 HC-Y
Dell	2130-C
Dell	2130-K
Dell	2130-M
Dell	2130-Y
Dell	2135 HC-C

Manufacturer	Toner Model #
Dell	2135 HC-K
Dell	2135 HC-M
Dell	2135 HC-Y
Dell	2135-C
Dell	2135-K
Dell	2135-M
Dell	2135-Y
Dell	2145-C
Dell	2145-K
Dell	2145-M
Dell	2145-Y
Dell	2150 HC-C
Dell	2150 HC-K
Dell	2150 HC-M
Dell	2150 HC-Y
Dell	2150-C
Dell	2150-K
Dell	2150-M
Dell	2150-Y
Dell	2155 HC-C
Dell	2155 HC-K
Dell	2155 HC-M
Dell	2155 HC-Y
Dell	2155-C
Dell	2155-K
Dell	2155-M
Dell	2155-Y
Dell	2230
Dell	2330 DRUM - K
Dell	2330-K
Dell	2335 HC-K
Dell	2335-K
Dell	2355
Dell	2355 HC
Dell	3110/3115 - C
Dell	3110/3115 - K
Dell	3110/3115 - M
Dell	3110/3115 - Y
Dell	3110/3115 HC - C
Dell	3110/3115 HC - K
Dell	3110/3115 HC - M
Dell	3110/3115 HC - Y
Dell	3130 HC-C
Dell	3130 HC-K
Dell	3130 HC-M
Dell	3130 HC-Y
Dell	3130-C
Dell	3130-K
Dell	3130-M
Dell	3130-Y
Dell	5130-C
Dell	5130-K
Dell	5130-M
Dell	5130-Y
Dell	5200
Dell	5210 - K
Dell	5330 - K
Dell	5330 HC - K
Dell	B116L - K

Manufacturer	Toner Model #
Dell	B116S - K
Dell	B116S - K Starter
Dell	B126L
Dell	B126S
Dell	B126S Starter
Dell	B2360
Dell	B2360 DRUM
Dell	B2360 Starter
Dell	B2375 - HC K
Dell	B2375 - K
Dell	B3460/5 - K
Dell	B3460/5 - K Starter
Dell	B3460/5 HC
Dell	B5460/5
Dell	B5460/5 HC
Dell	B5460/5 Starter
Dell	C1660 - C
Dell	C1660 - C Starter
Dell	C1660 - K
Dell	C1660 - K Starter
Dell	C1660 - M
Dell	C1660 - M Starter
Dell	C1660 - Y
Dell	C1660 - Y Starter
Dell	C1660 HC - C
Dell	C1660 HC - K
Dell	C1660 HC - M
Dell	C1660 HC - Y
Dell	C2660 - C
Dell	C2660 - C Starter
Dell	C2660 - K
Dell	C2660 - K Starter
Dell	C2660 - M
Dell	C2660 - M Starter
Dell	C2660 - Y
Dell	C2660 - Y Starter
Dell	C3760 HC - C
Dell	C3760 HC - K
Dell	C3760 HC - M
Dell	C3760 HC - Y
Dell	C3760-C
Dell	C3760-K
Dell	C3760-M
Dell	C3760-Y
Dell	M5200
Dell	S2500-K
Dell	S5200-K
Dell	S5210-K
Dell	S5310-K



Empties Please

Manufacturer	Toner Model #
Epson	S050166 (EPL 6200)
Epson	S050167 (EPL 6200 HC)
Epson	S050435 (0435)
Epson	S050435 (0435) Starter
Epson	S050436 (M2000)
Epson	S050436 (M2000) Starter
Epson	S050437 (M2000 HC)
Epson	S050437 (M2000 HC) Starter
Epson	S050438 (M2000)
Epson	S050438 (M2000) Starter
Epson	S050520 (M1200)
Epson	S050521 (M1200)
Epson	S050522 (M1200)
Epson	S050523 (M1200 HC)
Epson	S050554 (C1600 HC) - Y
Epson	S050555 (C1600 HC) - M
Epson	S050556 (C1600 HC) - C
Epson	S050557 (C1600) - K
Epson	S050558 (C1600) - Y
Epson	S050559 (C1600) - M
Epson	S050560 (C1600) - C
Epson	S050582 (M2300 HC)
Epson	S050582 (M2300 HC) Starter
Epson	S050583 (M2300)
Epson	S050583 (M2300) Starter
Epson	S050584 (M2400)
Epson	S050584 (M2400) Starter
Epson	S050585 (M2400 HC)
Epson	S050585 (M2400 HC) Starter
Epson	S050590 (0590) Y
Epson	S050591 (0591) M
Epson	S050592 (0592) C
Epson	S050593 (0593) K
Epson	S050602 (0602) Y
Epson	S050603 (0603) M
Epson	S050604 (0604) C
Epson	S050605 (0605) K
Epson	S050611 (C1700 HC)-Y
Epson	S050612 (C1700 HC)-M
Epson	S050613 (C1700 HC)-C
Epson	S050614 (C1700 HC)-K
Epson	S050627 (C2900) - Y
Epson	S050628 (C2900) - M

Manufacturer	Toner Model #
Epson	S050629 (C2900) - C
Epson	S050630 (C2900) - K
Epson	S050650 (0650) HC
Epson	S050651 (0651) HC
Epson	S050652 (0652)
Epson	S050669 (C1700)-Y
Epson	S050670 (C1700)-M
Epson	S050671 (C1700)-C
Epson	S050672 (C1700)-K
Epson	S050689 (M300 HC)
Epson	S050690 (M300)
Epson	S050690 (M300) Starter
Epson	S050691 (M300 HC)
Epson	S051104-DRUM
Epson	S051111 (N3000)
Epson	S051124 (C3800 HC)-Y
Epson	S051125 (C3800 HC)-M
Epson	S051126 (C3800 HC)-C
Epson	S051127 (C3800 HC)-K
Epson	S051128 (C3800)-Y
Epson	S051129 (C3800)-M
Epson	S051130 (C3800)-C
Epson	S051158 (C2800 HC)-Y
Epson	S051159 (C2800 HC)-M
Epson	S051160 (C2800 HC)-C
Epson	S051161 (C2800 HC)-K
Epson	S051162 (C2800)-Y
Epson	S051163 (C2800)-M
Epson	S051164 (C2800)-C
Epson	S051165 (C2800)-K



Empties Please

Manufacturer	Toner Model #
HP	We recycle ANY HP 'branded' toner

 **Empties Please**

Manufacturer	Toner Model #
Kyocera	TK100-K
Kyocera	TK110-K
Kyocera	TK1115
Kyocera	TK1125
Kyocera	TK1130-K
Kyocera	TK1140-K
Kyocera	TK120-K
Kyocera	TK130-K
Kyocera	TK140-K
Kyocera	TK150-C
Kyocera	TK150-K
Kyocera	TK150-M
Kyocera	TK150-Y
Kyocera	TK160-K
Kyocera	TK170-K
Kyocera	TK3100
Kyocera	TK310-K
Kyocera	TK3110
Kyocera	TK3130
Kyocera	TK320-K
Kyocera	TK330-K
Kyocera	TK340-K
Kyocera	TK350-K
Kyocera	TK360-K
Kyocera	TK450-K
Kyocera	TK5135-C
Kyocera	TK5135-K
Kyocera	TK5135-K
Kyocera	TK5135-M
Kyocera	TK5135-Y
Kyocera	TK540-C
Kyocera	TK540-K
Kyocera	TK540-M
Kyocera	TK540-Y
Kyocera	TK560-C
Kyocera	TK560-K
Kyocera	TK560-M
Kyocera	TK560-Y
Kyocera	TK570-C
Kyocera	TK570-K
Kyocera	TK570-M
Kyocera	TK570-Y
Kyocera	TK580-C
Kyocera	TK580-K
Kyocera	TK580-M
Kyocera	TK580-Y
Kyocera	TK590-C
Kyocera	TK590-K
Kyocera	TK590-M
Kyocera	TK590-Y
Kyocera	TK6305-K
Kyocera	TK6705 - K
Kyocera	TK8305-C
Kyocera	TK8305-K

Manufacturer	Toner Model #
Kyocera	TK8305-M
Kyocera	TK8305-Y
Kyocera	TK8315-C
Kyocera	TK8315-K
Kyocera	TK8315-M
Kyocera	TK8315-Y
Kyocera	TK8325 - C
Kyocera	TK8325 - K
Kyocera	TK8325 - M
Kyocera	TK8325 - Y
Kyocera	TK8505 - C
Kyocera	TK8505 - K
Kyocera	TK8505 - M
Kyocera	TK8505 - Y
Kyocera	TK8600 - C
Kyocera	TK8600 - K
Kyocera	TK8600 - M
Kyocera	TK8600 - Y
Kyocera	TK8705 - C
Kyocera	TK8705 - K
Kyocera	TK8705 - M
Kyocera	TK8705 - Y
Kyocera	TK895-C
Kyocera	TK895-K
Kyocera	TK895-M
Kyocera	TK895-Y



Empties Please

Manufacturer	Toner Model #
Lexmark	C500-C
Lexmark	C500-K
Lexmark	C500-M
Lexmark	C500-Y
Lexmark	C502-C
Lexmark	C502-K
Lexmark	C502-M
Lexmark	C502-Y
Lexmark	C510-C
Lexmark	C510-K
Lexmark	C510-M
Lexmark	C510-Y
Lexmark	C522-C
Lexmark	C522-K
Lexmark	C522-M
Lexmark	C522-Y
Lexmark	C524-C
Lexmark	C524-K
Lexmark	C524-M
Lexmark	C524-Y
Lexmark	C530-C
Lexmark	C530-K
Lexmark	C530-M
Lexmark	C530-Y
Lexmark	C532-C
Lexmark	C532-K
Lexmark	C532-M
Lexmark	C532-Y
Lexmark	C534-C
Lexmark	C534-K
Lexmark	C534-M
Lexmark	C534-Y
Lexmark	C540-C
Lexmark	C540-K
Lexmark	C540-M
Lexmark	C540-Y
Lexmark	C543-C
Lexmark	C543-K
Lexmark	C543-M
Lexmark	C543-Y
Lexmark	C544-C
Lexmark	C544-K
Lexmark	C544-M
Lexmark	C544-Y
Lexmark	C710-C
Lexmark	C710-K
Lexmark	C710-M
Lexmark	C710-Y
Lexmark	C720-C
Lexmark	C720-K
Lexmark	C720-M
Lexmark	C720-Y
Lexmark	C734-C
Lexmark	C734-K
Lexmark	C734-M
Lexmark	C734-Y
Lexmark	C736-C
Lexmark	C736-K
Lexmark	C736-M

Manufacturer	Toner Model #
Lexmark	C750-K
Lexmark	C750-M
Lexmark	C750-Y
Lexmark	C752-C
Lexmark	C752-K
Lexmark	C752-M
Lexmark	C752-Y
Lexmark	C762-C
Lexmark	C762-K
Lexmark	C762-M
Lexmark	C762-Y
Lexmark	C770-C
Lexmark	C770-K
Lexmark	C770-M
Lexmark	C770-Y
Lexmark	C772-C
Lexmark	C772-K
Lexmark	C772-M
Lexmark	C772-Y
Lexmark	C780-C
Lexmark	C780-K
Lexmark	C780-M
Lexmark	C780-Y
Lexmark	C782-C
Lexmark	C782-K
Lexmark	C782-M
Lexmark	C782-Y
Lexmark	C792 (C792A1CG) - CYAN
Lexmark	C792 (C792A1KG) - BLACK
Lexmark	C792 (C792A1MG) - MAGENTA
Lexmark	C792 (C792A1YG) - YELLOW
Lexmark	C792 (C792X1CG) - HC CYAN
Lexmark	C792 (C792X1KG) - HC BLACK
Lexmark	C792 (C792X1MG) - HC MAGENTA
Lexmark	C792 (C792X1YG) - HC YELLOW
Lexmark	C910-C
Lexmark	C910-K
Lexmark	C910-M
Lexmark	C910-Y
Lexmark	C912-C
Lexmark	C912-K
Lexmark	C912-M
Lexmark	C912-Y
Lexmark	C920-C
Lexmark	C920-K
Lexmark	C920-M
Lexmark	C920-Y
Lexmark	C925 C
Lexmark	C925 K
Lexmark	C925 M
Lexmark	C925 Y
Lexmark	C950 - C
Lexmark	C950 - K
Lexmark	C950 - M
Lexmark	C950 - Y
Lexmark	CS310/410/510-C
Lexmark	CS310/410/510-C Starter
Lexmark	CS310/410/510-K
Lexmark	CS310/410/510-K Starter

Manufacturer	Toner Model #
Lexmark	CS410-Y
Lexmark	CS410-Y Starter
Lexmark	CS510-C
Lexmark	CS510-C Starter
Lexmark	CS510-K
Lexmark	CS510-K Starter
Lexmark	CS510-M
Lexmark	CS510-M Starter
Lexmark	CS510-Y
Lexmark	CS510-Y Starter
Lexmark	CS748 - C
Lexmark	CS748 - K
Lexmark	CS748 - M
Lexmark	CS748 - Y
Lexmark	CX310
Lexmark	CX310 Starter
Lexmark	CX310/410/510-C
Lexmark	CX310/410/510-C Starter
Lexmark	CX310/410/510-K
Lexmark	CX310/410/510-K Starter
Lexmark	CX310/410/510-M
Lexmark	CX310/410/510-M Starter
Lexmark	CX310/410/510-Y
Lexmark	CX310/410/510-Y Starter
Lexmark	CX410-C
Lexmark	CX410-C Starter
Lexmark	CX410-K
Lexmark	CX410-K Starter
Lexmark	CX410-M
Lexmark	CX410-M Starter
Lexmark	CX410-Y
Lexmark	CX410-Y Starter
Lexmark	CX510-C
Lexmark	CX510-C Starter
Lexmark	CX510-K
Lexmark	CX510-K Starter
Lexmark	CX510-M
Lexmark	CX510-M Starter
Lexmark	CX510-Y
Lexmark	CX510-Y Starter
Lexmark	E120 DRUM-K
Lexmark	E120-K
Lexmark	E210-K
Lexmark	E220-K
Lexmark	E230-K
Lexmark	E232-K
Lexmark	E250 (E250A11)-K
Lexmark	E250 DRUM-K
Lexmark	E260 DRUM-K
Lexmark	E260-K
Lexmark	E310 (13T0101)-K
Lexmark	E320-K
Lexmark	E321 (12A7400)-K
Lexmark	E322-K
Lexmark	E323 (12A7405)-K
Lexmark	E330-K
Lexmark	E332-K
Lexmark	E340-K
Lexmark	E342-K



Empties Please

Manufacturer	Toner Model #
Lexmark	M3150
Lexmark	M5155 - HC BLACK
Lexmark	MS310/410/510/610
Lexmark	MS310/410/510/610 Starter
Lexmark	MS410/510/610 HC
Lexmark	MS510/610 EXTRA HC
Lexmark	MS710
Lexmark	MS710 Starter
Lexmark	MS711
Lexmark	MS711 Starter
Lexmark	MS810/811/812
Lexmark	MS810/811/812 Starter
Lexmark	MS811
Lexmark	MS811 Starter
Lexmark	MS811/812 HC
Lexmark	MS812
Lexmark	MS812 Starter
Lexmark	MX310/410/510/511/610/611
Lexmark	MX310/410/510/511/610/611 Starter
Lexmark	MX510/511/611 HC
Lexmark	MX710/711/810/811/812
Lexmark	MX710/711/810/811/812 Starter
Lexmark	MX711
Lexmark	MX711 Starter
Lexmark	MX711/810/811/812 HC
Lexmark	MX810
Lexmark	MX810 Starter
Lexmark	MX811
Lexmark	MX811 Starter
Lexmark	MX812
Lexmark	MX812 Starter
Lexmark	T420-K
Lexmark	T430-K
Lexmark	T520-K
Lexmark	T522-K
Lexmark	T610-K
Lexmark	T612-K
Lexmark	T614-K
Lexmark	T616-K
Lexmark	T620-K
Lexmark	T622-K
Lexmark	T630-K
Lexmark	T632-K
Lexmark	T634-K
Lexmark	T640-K
Lexmark	T642-K
Lexmark	T644-K
Lexmark	T650-K
Lexmark	T652-K
Lexmark	T654-K
Lexmark	X203
Lexmark	X215
Lexmark	X264-K
Lexmark	X340-K
Lexmark	X342-K
Lexmark	X363-K
Lexmark	X364-K
Lexmark	X422-K
Lexmark	X500-C
Lexmark	X500-K

Manufacturer	Toner Model #
Lexmark	X642-K
Lexmark	X644-K
Lexmark	X646-K
Lexmark	X651-K
Lexmark	X652-K
Lexmark	X654-K
Lexmark	X656-K
Lexmark	X658-K
Lexmark	X720-C
Lexmark	X720-K
Lexmark	X720-M
Lexmark	X720-Y
Lexmark	X746 C
Lexmark	X746 K
Lexmark	X746 M
Lexmark	X746 Y
Lexmark	X750-C
Lexmark	X750-K
Lexmark	X750-M
Lexmark	X750-Y
Lexmark	X752-C
Lexmark	X752-K
Lexmark	X752-M
Lexmark	X752-Y
Lexmark	X762-C
Lexmark	X762-K
Lexmark	X762-M
Lexmark	X762-Y
Lexmark	X782-C
Lexmark	X782-K
Lexmark	X782-M
Lexmark	X782-Y
Lexmark	X792 - C
Lexmark	X792 - K
Lexmark	X792 - M
Lexmark	X792 - Y
Lexmark	X850-K
Lexmark	X852-K
Lexmark	X854-K
Lexmark	X912-C
Lexmark	X912-K
Lexmark	X912-M
Lexmark	X912-Y
Lexmark	XC2132 - C
Lexmark	XC2132 - K
Lexmark	XC2132 - M
Lexmark	XC2132 - Y
Lexmark	XS544 C
Lexmark	XS544 K
Lexmark	XS544 M
Lexmark	XS544 Y
Lexmark	XS748 C
Lexmark	XS748 HC - C
Lexmark	XS748 HC - K
Lexmark	XS748 HC - M
Lexmark	XS748 HC - Y
Lexmark	XS748 K
Lexmark	XS748 M
Lexmark	XS748 Starter - C
Lexmark	XS748 Starter - K

Manufacturer	Toner Model #
Lexmark	C736-Y
Lexmark	C746 - C
Lexmark	C746 - K
Lexmark	C746 - M
Lexmark	C746 - Y
Lexmark	C748 - C
Lexmark	C748 - K
Lexmark	C748 - M
Lexmark	C748 - Y
Lexmark	C750-C
Lexmark	CS310/410/510-M
Lexmark	CS310/410/510-M Starter
Lexmark	CS310/410/510-Y
Lexmark	CS310/410/510-Y Starter
Lexmark	CS410-C
Lexmark	CS410-C Starter
Lexmark	CS410-K
Lexmark	CS410-K Starter
Lexmark	CS410-M
Lexmark	CS410-M Starter
Lexmark	E350 DRUM-K
Lexmark	E350-K
Lexmark	E352 DRUM-K
Lexmark	E352-K
Lexmark	E360 DRUM-K
Lexmark	E360-K
Lexmark	E450 DRUM-K
Lexmark	E450-K
Lexmark	E460 DRUM-K
Lexmark	E460-K
Lexmark	X500-M
Lexmark	X500-Y
Lexmark	X520-K
Lexmark	X522-K
Lexmark	X620-K
Lexmark	X622-K
Lexmark	X630-K
Lexmark	X632-K
Lexmark	X634-K
Lexmark	XS748 Starter - M
Lexmark	XS748 Starter - Y
Lexmark	XS748 Y

Manufacturer	Toner Model #
OKI	44250721 - Y (C110 HC)
OKI	44250722 - M (C110 HC)
OKI	44250723 - C (C110 HC)
OKI	44250724 - K (C110 HC)
OKI	B2200
OKI	B2200 HC
OKI	B2400
OKI	B2400 HC
OKI	B2500
OKI	B410 HC - K
OKI	B410-K
OKI	B410XL-K
OKI	B4200-K
OKI	B4400-K
OKI	B4600-K
OKI	B6100-K
OKI	B6200-K
OKI	B6300
OKI	B6500 (09004461) - K
OKI	B6500 (09004462) - HC K
OKI	B710
OKI	C110 -C Starter
OKI	C110 -K Starter
OKI	C110 -M Starter
OKI	C110 -Y Starter
OKI	C110-C
OKI	C110-K
OKI	C110-M
OKI	C110-Y
OKI	C310/510-C
OKI	C310/510-K
OKI	C310/510-M
OKI	C310/510-Y
OKI	C3300/400 - C
OKI	C3300/400 - K
OKI	C3300/400 - M
OKI	C3300/400 - Y
OKI	C5600/800 - C
OKI	C5600/800 - K
OKI	C5600/800 - M
OKI	C5600/800 - Y
OKI	C7100-C
OKI	C7100-K
OKI	C7100-M
OKI	C7100-Y
OKI	C710-C

Manufacturer	Toner Model #
OKI	C710-K
OKI	C710-M
OKI	C710-Y
OKI	C7200-C
OKI	C7200-K
OKI	C7200-M
OKI	C7200-Y
OKI	C831 - C
OKI	C831 - K
OKI	C831 - M
OKI	C831 - Y
OKI	C8600/800 - C
OKI	C8600/800 - K
OKI	C8600/800 - M
OKI	C8600/800 - Y
OKI	C9200/600 - C
OKI	C9200/600 - K
OKI	C9200/600 - M
OKI	C9200/600 - Y



Empties Please

Manufacturer	Toner Model #
Samsung	We recycle ANY Samsung 'branded' toner



Manufacturer	Toner Model #
Xerox	106R01050 (7400) - C
Xerox	106R01051 (7400) - M
Xerox	106R01052 (7400) - Y
Xerox	106R01076 (6300)-K
Xerox	106R01077 (7400 HC) - C
Xerox	106R01078 (7400 HC) - M
Xerox	106R01079 (7400 HC) - Y
Xerox	106R01080 (7400 HC) - K
Xerox	106R01144 (6350)-C
Xerox	106R01145 (6350)-M
Xerox	106R01146 (6350)-Y
Xerox	106R01148 (3500)
Xerox	106R01150 (7400) - K
Xerox	106R01151 (7400) - M
Xerox	106R01152 (7400) - Y
Xerox	106R01159 (3117)
Xerox	106R01164 (7760) - C
Xerox	106R01165 (7760) - M
Xerox	106R01166 (7760) - Y
Xerox	106R01167 (7760) - K
Xerox	106R01278 (6130) - C
Xerox	106R01279 (6130) - M
Xerox	106R01280 (6130) - Y
Xerox	106R01281 (6130) - K
Xerox	106R01331 (6125) - C
Xerox	106R01332 (6125) - M
Xerox	106R01333 (6125) - Y
Xerox	106R01334 (6125) - K
Xerox	106R01373 (3250)
Xerox	106R01374 (3250 HC)
Xerox	106R01378 (3100)
Xerox	106R01379 (3100 HC)
Xerox	106R01388 (6280) - C
Xerox	106R01389 (6280) - M
Xerox	106R01390 (6280) - Y
Xerox	106R01391 (6280) - K
Xerox	106R01392 (6280 HC) - C
Xerox	106R01393 (6280 HC) - M
Xerox	106R01394 (6280 HC) - Y
Xerox	106R01395 (6280 HC) - K
Xerox	106R01433 (7500) - C
Xerox	106R01434 (7500) - M
Xerox	106R01435 (7500) - Y
Xerox	106R01436 (7500 HC) - C
Xerox	106R01437 (7500 HC) - M
Xerox	106R01438 (7500 HC) - Y
Xerox	106R01439 (7500 HC) - K
Xerox	106R01452 (6128) - C
Xerox	106R01452 (6128) - C Starter
Xerox	106R01452 (6128) -K
Xerox	106R01452 (6128) -K Starter
Xerox	106R01453 (6128) -M
Xerox	106R01453 (6128) -M Starter
Xerox	106R01454 (6128) -Y
Xerox	106R01454 (6128) -Y Starter
Xerox	106R01455 (6128) - K
Xerox	106R01455 (6128) - K Starter
Xerox	106R01463 (6121) - C
Xerox	106R01464 (6121) - M

Manufacturer	Toner Model #
Xerox	106R01464 (6121) - Y
Xerox	106R01466 (6121 HC) - C
Xerox	106R01467 (6121 HC) - M
Xerox	106R01468 (6121 HC) - Y
Xerox	106R01469 (6121 HC) - K
Xerox	106R01477 - C
Xerox	106R01478 - M
Xerox	106R01479 - Y
Xerox	106R01480 - K
Xerox	106R01503 (6700) - C
Xerox	106R01504 (6700) - M
Xerox	106R01505 (6700) - Y
Xerox	106R01506 (6700) - K
Xerox	113R00184-K
Xerox	106R01507 (6700 HC) - C
Xerox	106R01508 (6700 HC) - M
Xerox	106R01509 (6700 HC) - Y
Xerox	106R01510 (6700 HC) - K
Xerox	106R01563 (7800) - C
Xerox	106R01564 (7800) - M
Xerox	106R01565 (7800) - Y
Xerox	106R01566 (7800 HC)-C
Xerox	106R01567 (7800 HC)-M
Xerox	106R01568 (7800 HC)-Y
Xerox	106R01569 (7800 HC)-K
Xerox	106R01591 (6500)-C
Xerox	106R01592 (6500)-M
Xerox	106R01593 (6500)-Y
Xerox	106R01594 (6500 HC)-C
Xerox	106R01595 (6500 HC)-M
Xerox	106R01596 (6500 HC)-Y
Xerox	106R01597 (6500 HC)-K
Xerox	106R01627 (6000)-C
Xerox	106R01628 (6000)-M
Xerox	106R01629 (6000)-Y
Xerox	106R01630 (6000)-K
Xerox	106R02229 (6600 HC)-C
Xerox	106R02229 (6600 HC)-C Starter
Xerox	106R02230 (6600 HC) Starter
Xerox	106R02230 (6600 HC)-M
Xerox	106R02231 (6600 HC) Starter
Xerox	106R02231 (6600 HC)-Y
Xerox	106R02232 (6600 HC)-K
Xerox	106R02232 (6600 HC)-K Starter
Xerox	106R02237 (6605) - C
Xerox	106R02238 (6605) - M
Xerox	106R02239 (6605) - Y
Xerox	106R02240 (6605) - K
Xerox	106R02245 (6600)-C
Xerox	106R02245 (6600)-C Starter
Xerox	106R02246 (6600)-M
Xerox	106R02246 (6600)-M Starter
Xerox	106R02247 (6600)-Y
Xerox	106R02247 (6600)-Y Starter
Xerox	106R02248 (6600)-K
Xerox	106R02248 (6600)-K Starter
Xerox	106R02599 (7100) - C
Xerox	106R02599 (7100) - C Starter
Xerox	106R02600 (7100) - M

Manufacturer	Toner Model #
Xerox	106R02600 (7100) - M Starter
Xerox	106R02601 (7100) - Y
Xerox	106R02601 (7100) - Y Starter
Xerox	106R02602 (7100 HC) - C
Xerox	106R02603 (7100 HC) - M
Xerox	106R02604 (7100 HC) - Y
Xerox	106R02605 (7100 HC) - K
Xerox	106R02721 (3610)
Xerox	106R02722 (3610)
Xerox	106R02723 (3610)
Xerox	106R02724 (3610)
Xerox	109R00725 (3115)
Xerox	109R00747 (3150 HC)
Xerox	113R00621-K
Xerox	113R00656 (4500)
Xerox	113R00657 (4500 HC)
Xerox	113R00711 (4510)
Xerox	113R00712 (4510 HC)
Xerox	113R00719 (6180) - C
Xerox	113R00720 (6180) - M
Xerox	113R00721 (6180) - Y
Xerox	113R00722 (6180) - K
Xerox	113R00723 (6180 HC) - C
Xerox	113R00724 (6180 HC) - M
Xerox	113R00725 (6180 HC) - Y
Xerox	113R00726 (6180 HC) - K
Xerox	113R00730 (3250 HC)
Xerox	113R00735 (3250)

 **Empties Please**

Manufacturer	Toner Model #
Konica Min	1600-C
Konica Min	1600-K
Konica Min	1600-M
Konica Min	1600-Y

Manufacturer	Toner Model #
Sharp	AL100TD

Manufacturer	Toner Model #
Ricoh	SP 1000 - G299-K
Ricoh	SP 3400-K
Ricoh	SP 4100 - Type 220-K
Ricoh	SP 5100 - M811-K
Ricoh	SP 6330-K
Ricoh	SP C220-C
Ricoh	SP C220-K
Ricoh	SP C220-M
Ricoh	SP C220-Y
Ricoh	SP C310-C
Ricoh	SP C310-K
Ricoh	SP C310-M
Ricoh	SP C310-Y